

GUARANTEE*

Arlec guarantees this product against defects of materials and workmanship for a period of 12 months from the date of purchase provided that the product is used in accordance with Arlec's recommendations and within such voltage and current limits as are specified by Arlec in relation to the product. Arlec will at its own option make good, replace with the same or similar product, or provide credit for any product manufactured or supplied by it, which proves to be defective within the limits set out above provided always that no repairs, alterations or modifications to the product have been undertaken or attempted, other than by the company or its authorised agents. Should the purchaser wish to make a claim under the guarantee, the product should be returned pre-paid to the place of purchase.

To obtain warranty the purchase receipt must be returned with the product. This guarantee is in addition to and does not take away from any rights available to the consumer under the Trade Practices Act and the State consumer protection legislation.

*Guarantee excludes globe.

Proof of Purchase

Please retain your receipt for all service or warranty claims.

ARLEC

For all Sales and Service enquiries
Phone (03) 9727 8860 Fax 1300 360 650

© This instruction leaflet is subject to copyright and must not be reproduced, copied or otherwise used in any way or for any purpose without the consent in writing of the owner, Arlec Australia Pty Ltd (A.C.N. 009 322 102). CPIN16692

ARLEC

Rechargeable Torch and Spotlight

RT500

Instruction Manual



Important! Please read these instructions carefully before use.

Due to continuous research and development the specifications herein are subject to change without notice.

INTRODUCTION

The Arlec Rechargeable Torch and Spotlight is a rechargeable torch with a Quartz Halogen globe providing intense white light.

BEFORE USE, CHARGE THE BATTERY

Plug the AC adaptor charger into the charger socket on the torch by first lifting up the rubber socket cover. Plug the adaptor into power and switch on. The time to fully charge the battery is approx. 12-15 hours.

On full charge the torch will operate for approx. 50-60 minutes before needing a recharge.

IMPORTANT: Do not store with flat battery. Recharge regularly. If the battery is flattened charge immediately. DO NOT CHARGE FOR A PERIOD IN EXCESS OF 24 HOURS.

After charging close the rubber socket cover. This will assist in maintaining the weather resistance of the torch.

TO USE

The torch can be operated with the handle in the normal position or in "pistol" grip position. This is achieved by pressing in the release button on the handle and rotating it to the desired position.



Normal Position

The stand on the underside of the torch may be set to a variety of angles just by rotating it into position. It will click into place as it goes around.

This can be used to set the torch at various angles when setting it down on a surface to direct it in a particular place, or allow hands free use.

The stand can also be used as an alternative handle.

Switch on by rotating the switch lever at the side of the torch as indicated.

Do not switch on while charging as damage will result.

WARNINGS

- Lens becomes very hot during operation. This torch is designed for intermittent use only. Continuous use is specifically not recommended and may cause damage to the unit.
- Never cover lens and reflector during operation.
- Do not shine directly into eyes.
- Switch off the torch and allow to cool before storage or maintenance.
- Replace the globe or battery with same rating and type only.
- Use only the chargers supplied with the lantern.



Pistol Grip Position



GLOBE REPLACEMENT

1. Remove the front of the torch by turning anticlockwise. Push gently on the glass to help keep the reflector assembly from turning also.
2. Lift out the reflector assembly and remove the spring wire clip from the rear of the reflector. Globe will now come away from reflector.
3. Disconnect the globe wire by pulling straight out on the connecting wire. Hold by the connecting lugs while doing so, not by the wire.
4. Replace the globe, reconnect the wire, fit spring wire clip and refit reflector assembly. Avoid handling the new globe by the glass envelope.

Globe is PK22S base rated 6 volt 25 watt. If brighter light is required a 6V 55 Watt globe can be used, but the runtime will be reduced. (approximately 30 minutes)

CAR CHARGER

A cigarette lighter charger is provided. It works in much the same way as the AC adaptor, but allows you to charge the torch from your vehicle.

To fully charge the torch via the cigarette lighter takes approx 6 hours. Avoid charging in excess of this time.

NOTE: Normally cigarette lighter outlets in vehicles will only be energised if the key is in the ignition and turned at least to the "ACC" position.

USER HINTS

- Do not store with flat battery. Always recharge unit before storing.
- Do not store or operate the unit under extreme temperature and/or high humidity.
- Keep unit away from direct sunlight.
- Clean the unit with a damp cloth with soap detergents only, do not use corrosive or abrasive cleaners.

IMPORTANT

- If the unit is to be kept in storage for any reason, charge before storing and recharge every 3-4 months to maintain battery life.